





Black & Decker

Model of lawnmower.	SPCM1936	CM1936	CM1836	MM1800
Stock photo of lawnmower.				
Type of lawnmower.	Self-Propelled	Push	Push	Push
Cordless or Corded	Cordless	Cordless	Cordless	Corded
Manufacturers Suggested Retail Price	\$499.00	\$449.00	\$329.00	\$229.00
Mower Price for Lawnmower Exchange Event	\$375.00	\$325.00	\$250.00	\$160.00
Do I have to put the lawnmower together?	No	No	No	Minimal
Does the lawnmower come with a warranty?	2 year	2 year	2 year	2 year
How much does the lawnmower weigh?	92 lbs	72 lbs	76 lbs	42 lbs
How much lawn does the lawnmower cut with a fully charged battery?	Up to 1/3 acre	Up to 1/3 acre	Up to 1/4 acre	within 100ft of an electrical outlet
How long does it take to charge battery?	12 hours	12 hours	10 hours	N/A
How wide is the lawnmower's cut?	19 inch	19 inch	18 inches	18 inches
How high or low can I cut my grass?	1.5 to 3.5 inches	1.5 to 3.5 inches	1.5 to 3.5 inches	1.25 to 3.5 inches
How long does the lawnmower run on a single charge?	Up to 45 minutes	Up to 45 minutes	Up to 45 minutes	N/A
What is the battery voltage?	36V Battery	36V Battery	36V Battery	Corded
What comes with the purchase of the lawnmower?	36V Charger, Rear-bag Assembly, Safety Key	36V Battery Charger, Rear-bag Assembly, Safety Key, Mulch Plug	36V Battery Charger, Rear-bag Assembly, Safety Key, Mulch Plug	Mulch Plug, Rear-bag Assembly